

SHERWIN WILLIAMS.

As of 10/26/2016, Complies with:				
OTC	Yes	LEED® 09 NC,CI,CS	Yes	
OTC Phase II	Yes	LEED® 09 H&S	Yes	
SCAQMD	Yes	LEED [®] v4 Emissons	Yes	
CARB	Yes	LEED [®] v4 VOC	Yes	
CARB SCM 2007	Yes			
MPI	Yes			

CHARACTERISTICS

ProMar 200 Zero VOC Interior Latex Flat is a durable, professional quality, washable, interior vinyl acrylic finish for use on walls and ceilings of primed plaster, wallboard, wood, masonry, and primed metal.

Color: Most colors To optimize hide and color development, always use the recommended P-Shade primer				
Coverage:	350 - 400 sq ft/gal			
@ 4 mils wet; 1.4 mils dry				
Drying Time, @ 77°F, 50% RH:				
Touch:	1 hour			
Recoat:	4 hours			
Drying and recoat times are temperature, humidity,				
and film thickness dependent				
Finish:	1.5-3.5 units @ 85°			
Flash Point:	N/A			

Tinting with CCE only:

oz/gal	Strength
0-5	100%
0-6	125%
4-12	100%
4-12	100%
4-12	100%
4-12	100%
	do not tint
	Vinyl Acrylic
	0-5 0-6 4-12 4-12 4-12

Extra White B30W12651 VOC (less exempt solvents):

<50 g/	L; 0.42 lb/gal
As per 40 CFR 59.406 and SOR/20	09-264, s.12
Volume Solids:	34 ± 2%
Weight Solids:	52 ± 2%
Weight per Gallon:	11.45 lb

Anti-microbial

This product contains agents which inhibit the growth of mold and mildew on the surface of this paint film.



101.81A

PROMAR[®] 200 Zero VOC Interior Latex Flat B30-2600 Series

SPECIFICATIONS

Block

1ct. PrepRite Block Filler* 2cts. ProMar 200 Zero VOC Interior Latex

Drywall

1ct. ProMar 200 Zero VOC Latex Primer 2cts. ProMar 200 Zero VOC Interior Latex

Masonry

1ct. Loxon Concrete & Masonry Primer* 2cts. ProMar 200 Zero VOC Interior Latex

Plaster

1ct. Premium Wall & Wood Primer* 2cts. ProMar 200 Zero VOC Interior Latex

Wood

1ct. Premium Wall & Wood Primer* 2cts. ProMar 200 Zero VOC Interior Latex

* These primers contain <50 g/L VOC.

Other primers may be appropriate.

When repainting involves a drastic color change, a coat of primer will improve the hiding performance of the topcoat color.

SURFACE PREPARATION

WARNING! Removal of old paint by sanding, scraping or other means may generate dust or fumes that contain lead. Exposure to lead dust or fumes may cause brain damage or other adverse health effects, especially in children or pregnant women. Controlling exposure to lead or other hazardous substances requires the use of proper protective equipment, such as a properly fitted respirator (NIOSH approved) and proper containment and cleanup. For more information, call the National Lead Information Center at 1-800-424-LEAD (in US) or contact your local health authority.

Remove all surface contamination by washing with an appropriate cleaner, rinse thoroughly and allow to dry. Existing peeled or checked paint should be scraped and sanded to a sound surface. Glossy surfaces should be sanded dull. Stains from water, smoke, ink, pencil, grease, etc. should be sealed with the appropriate primer/sealer. Recognize that any surface preparation short of total removal of the old coating may compromise the service length of the system.

Drywall

Fill cracks and holes with patching paste/ spackle and sand smooth. Joint compounds must be cured and sanded smooth. Remove all sanding dust.

Masonry, Concrete, Cement, Block

All new surfaces must be cured according to the supplier's recommendations usually about 30 days. Remove all form release and curing agents. Rough surfaces can be filled to provide a smooth surface. If painting cannot wait 30 days, allow the surface to cure 7 days and prime the surface with Loxon Concrete & Masonry Primer.



101.81

PROMAR[®] 200 Zero VOC Interior Latex Flat B30-2600 Series

SURFACE PREPARATION	APPLICATION	CAUTIONS
SURFACE PREPARATION Plaster Bare plaster must be cured and hard. Textured, soft, porous, or powdery plaster should be treated with a solution of 1 pint household vinegar to 1 gallon of water. Repeat until the surface is hard, rinse with clear water and allow to dry. Wood Sand any exposed wood to a fresh surface. Patch all holes and imperfections with a wood filler or putty and sand smooth. Mildew Prior to attempting to remove mildew, it is always recommended to test any cleaner on a small, inconspicuous area prior to use. Bleach and bleaching type cleaners may damage or discolor existing paint films. Bleach alternative cleaning solutions may be advised. Mildew may be removed before painting by washing with a solution of 1 part liquid bleach and 3 parts water. Apply the solution and scrub the mildewed area. Allow the solution to remain on the surface for 10 minutes. Rinse thoroughly with water and allow the surface to dry before painting. Wear protective eyewear, waterproof gloves, and protective clothing. Quickly wash off any of the mixture that comes in contact with your skin. Do not add detergents or ammonia to the bleach/water solution.	APPLICATION Apply at temperatures above 50°F. No reduction needed. Brush Use a nylon/polyester brush. Roller Use a 3/8" - 3/4" nap synthetic cover. Spray—Airless Pressure	CAUTIONSFor interior use only Protect from freezing. Non-photochemically reactive.Before using, carefully read CAUTIONS on labelHOTW 10/26/2016B30W12651 04 00 FRC,SP,KORCLEANUP INFORMATIONClean spills, spatters, hands and tools immediately after use with soap and warm water. After cleaning, flush spray equipment with compliant cleanup solvent to prevent rusting of the equipment. Follow manufacturer's safety recommendations when using solvents.
Caulking Gaps between walls, ceilings, crown moldings, and other interior trim can be filled with the appropriate caulk after priming the surface.		The information and recommendations set forth in
		this Product Data Sheet are based upon tests conducted by or on behalf of The Sherwin-Williams Company. Such information and recommendations set forth herein are subject to change and pertain to the product offered at the time of publication. Consult your Sherwin-Williams representative or visit www.paintdocs.com to obtain the most current version of the PDS and/or an SDS.