

Sherwin Williams.

professional.

As of 02/08/2017, Complies with:				
OTC	No	LEED® 09 NC, CI	No	
OTC Phase II	No	LEED [®] 09 CS	No	
SCAQMD	No	LEED [®] 09 H&S	No	
CARB	No	LEED [®] V4 Emissions	No	
CARB SCM2007	No	LEED [®] V4 VOC	No	
Canada	No	MPI	Yes	

CHARACTERISTICS

ProMar 200 Interior Alkyd Semi-Gloss E is a quality product designed for the 1

product

This

PROMAR[®] 200 Interior Alkyd Semi-Gloss

B34W00207 Luminous White B34W00251 Extra White B34W00253 Deep Base

SURFACE PREPARATION

WARNING! Removal of old paint by sanding, scraping or other means may generate dust or fumes that contain lead. Exposure to lead dust or fumes may cause brain damage or other adverse health effects, especially in children or pregnant women. Controlling exposure to lead or other hazardous substances requires the use of proper protective equipment, such as a properly fitted respirator (NIOSH approved) and proper containment and cleanup. For more information, call the National Lead Information Center at 1-800-424-LEAD (in US) or contact your local health authority.

Remove all surface contamination by washing with an appropriate cleaner, rinse thoroughly and allow to dry. Existing peeled or checked paint should be scraped and sanded to a sound surface. Glossy surfaces should be sanded dull. Stains from water, smoke, ink, pencil, grease, etc. should be sealed with an appropriate primer/sealer. Recognize that any surface preparation short of total removal of the old coating may compromise the service length of the system.

Drywall

Fill cracks and holes with patching paste/ spackle and sand smooth. Joint compounds must be cured and sanded smooth. Remove all sanding dust.

Masonry, Concrete, Cement, Block

All new surfaces must be cured according to the supplier's recommendations usually about 30 days. Remove all form release and curing agents. Rough surfaces can be filled to provide a smooth surface. If painting cannot wait 30 days, allow the surface to cure 7 days and prime the surface with Loxon Concrete & Masonry Primer.

recommended for interior app	lication on	
primed plaster, wallboard	l, wood,	
masonry, and primed metal.		
		ļ
Color: M	ost colors	
To optimize hide and color development	nt, always use	
the recommended P-Shade primer		
Coverage: 350 - 40	0 sq ft/gal	
@ 4 mils wet; 1.	7 mils dry	
Drying Time, @ 77°F, 50% RH	l:	
Touch:	2-4 hours	
Recoat:	24 hours	

Recoat: 24 hours Drying and recoat times are temperature, humidity, and film thickness dependent

Finish:

24 hours	45-55 units @ 60°
30 days	30-40 units @ 60°
Flash Point:	117°F, PMCC

Tinting with Blend-A-Color:Baseoz/galStrengthExtra White0-5100%Deep Base4-12100%Luminous White0-5125%Vehicle Type:Alkyd

Extra White B34W00251 VOC (less exempt solvents):

	444 g/L; 3.70 lb/gal
As per 40 CFR 59.406 and	SOR/2009-264, s.12
Volume Solids:	43 ± 2%
Weight Solids:	62 ± 2%
Weight per Gallon:	9.85 lb

SPECIFICATIONS

s Block

is

1ct. Loxon Block Surfacer 2cts. ProMar 200 Alkyd Semi-Gloss

Drywall 1ct. ProMar 200 Latex Primer 2cts. ProMar 200 Alkyd Semi-Gloss

Plaster

1ct. Premium Wall and Wood Primer 2cts. ProMar 200 Alkyd Semi-Gloss

Masonry

1ct. Loxon Concrete and Masonry Primer 2cts. ProMar 200 Alkyd Semi-Gloss

Wood

1ct. Premium Wall and Wood Primer 2cts. ProMar 200 Alkyd Semi-Gloss

Other primers may be appropriate.

When repainting involves a drastic color change, a coat of primer will improve the hiding performance of the topcoat color.



103.32

PROMAR[®] 200 Interior Alkyd Semi-Gloss

B34W00207 Luminous White B34W00251 Extra White B34W00253 Deep Base

SURFACE PREPARATION	APPLICATION	CAUTIONS	
PlasterBare plaster must be cured and hard.Textured, soft, porous, or powdery plastershould be treated with a solution of 1 pinthousehold vinegar to 1 gallon of water.Repeat until the surface is hard, rinsewith clear water and allow to dry.WoodSand any exposed wood to a fresh	Use a natural bristle brush. Roller Use a 1/4" - 3/4" nap synthetic or lambswool cover. Spray-Airless Pressure	Non-Photochemically Reactive For exterior use on doors, trim, and other small areas of wood or metal. Do not use on the main body of exterior structures. Do not use colorants formulated for interior use only. Before using, carefully read CAUTIONS on label.	
surface. Patch all holes and imperfections with a wood filler or putty and sand smooth.	Tip	HOTW 02/08/2017 B34W00251 18 443	
	CLEANUP INFORMATION Clean spills, spatters and tools immediately after use with compliant cleanup solvent. Follow manufacturer's safety recommendations when using solvents. DANGER Rags, steel wool, other waste soaked with this product, and sanding residue may spontaneously catch fire if improperly discarded. Immediately place rags, steel wool, other waste soaked with this product, and sanding residue in a sealed, water-filled, metal container. Dispose of in accordance with local fire regulations.	The information and recommendations set forth in this Product Data Sheet are based upon tests conducted by or on behalf of The Sherwin-Williams Company. Such information and recommendations set forth herein are subject to change and pertain to the product offered at the time of publication. Consult your Sherwin-Williams representative or visit www.paintdocs.com to obtain the most current version of the PDS and/or an SDS.	